


INSTALLATION NOTES

1. Disconnect the negative battery cable. Disconnect the wires to the module mounted on the fan shroud. Remove the module, fan shroud, and fan from the truck. (Fan nut has right hand threads). Remove the O.E.M. accessory drive belt.
2. Remove the four bolts holding the A/C compressor to the A/C bracket. Place the two spacers (4) under the A/C compressor at the two holes to the inside. Install bolts and flat washers (10 & 11) into those two holes loosely. Install the aux. A.C. compressor onto bracket (2) with bolts (15,16), nuts (17) and slide bushings (18). Install compressor and pump assembly (2) under the A/C compressor with bolts and flat washers (10 & 11) at locations "A & B", and bolts (7) with lock washers (12) at locations "C & D". Do Not Tighten.
3. Install the idler assembly on the backside of bracket using the bottom slot for 2001 model trucks, and the top slot for 2002 and later models. Do not tighten. Install the belt (14) around the A/C and clutch pump pulleys before installing bracket (1). Remove the three bolts holding the P/S pump plate to the aluminum bracket at locations "E, F & G". Install bracket (1) using bolts (7 & 8) with lock washers (12) and spacers (3). Tighten all bolts very lightly, and then tighten them securely.
4. Install the belt onto all the idlers and pulleys as shown in the diagram. Retract the tensioner and slide the idler (6) down until it takes up most of the belt slack, tighten the idler bolt and release the tensioner.
5. Replace the fan, shroud and module back onto the vehicle. Reconnect the module and the battery cable. Run the engine to make sure the belt tracks properly and nothing comes in contact with any moving parts. Adjust if necessary.

NOTE: This kit only requires one belt. The extra belt is to be placed in the vehicle for future use because this belt is not available over the counter.

CAUTION: Check all engine compartment vacuum hoses and electrical wiring that may have been disturbed or re-routed during kit installation to be sure that hoses are not kinked, that they do not touch any high temperature item, and that they do not interfere with any linkage components.

CMK69SD508-I6
2001-10 Chevy
C&K 2500 HD & 3500
6.6 V-8 Duramax Diesel
W/O Dual Alternator



PARTS LIST

- | | |
|--|---------------------------------|
| 1. CMB 691 (1) | 10. 10mm x 100mm (4) |
| 2. CMP 68SD508 (1) | 11. 10mm FW (4) |
| 3. SP64-1.500 (3) | 12. 10mm LW (7) |
| 4. SP88-0.375 (2) | 13. 10mm Flange Nut (1) |
| <i>(TIPKSC-68 Includes Items 5,6,9,13)</i> | 14. 5061380 (2) |
| 5. CMB 3867 (1) | 15. 10mm x 30mm Flange Bolt (2) |
| 6. 89007 Dayco (1) | 16. 10mm x 40mm Flange Bolt (2) |
| 7. 10mm x 25mm 10.9 (4) | 17. 10mm Flange Nut (2) |
| 8. 10mm x 90mm 10.9 (3) | 18. 1255-0090 Slide Bushing (2) |
| 9. 10mm x 50mm Flange Bolt (1) | |