

CW Mill Equipment Co., Inc. 14 Commerce Drive Sabetha, KS 66534 Phone: (785) 284-3454 Fax: (785) 284-3601 Email: brackets@cwmill.com MOUNTING KITS Website: www.cwkits.com

NOTE: ON 2008 & NEWER 5.4 IT IS THE INSTALLERS **RESPONSIBILITY TO PURCHASE NEW BALANCER** WITH HOLES FROM FORD PART#7L3Z-6312-A

FMK46A-8 1999-04 FORD TRUCK F250-550 Super Duty 1997-19 FORD VAN E150-450 5.4LV8 Gas Triton & 6.8LV10 Gas Triton For use W-WO AC / Requires SAE Two Bolt "A" Flange Pump / Requires 8 Groove Clutch / **Recommended no more than 5HP Load Per Ford Motor Company** 

## **INSTALLATION NOTES**

- 1. Disconnect the negative battery cable. On E series, remove the complete air cleaner assembly. Remove the fan and fan shroud. (Fan nut has right hand threads). Remove the O.E.M. serpentine belt and the flat idler on the passenger side of the engine. Remove the studs at locations "A & D" & install studs (5) with flat washers (6). Torque studs to 35 ft/lbs. Remove bolts at locations "B & C".
- 2. Install drive pulley (1) onto the harmonic balancer with bolts (2) and lock washers (3). Torque bolts to 40 ft/lbs. Install the pump into the back of bracket (4) with bolts (15), flat washers (16) and lock washers (17) and nuts (18). Install the coil and clutch as per manufacturers instructions. Install the pump and bracket assembly onto the studs at locations "A & D". Install bolts (7) with lock washers (3) at locations "B & C", and nuts (8) with lock washers (3) at locations "A & D". Tighten bolts and nuts evenly, and then torque them to 35-40 ft/lbs.
- 3. Replace the OEM idler back to its original location. Replace the OEM belt. Install pump belt tensioner (9) with bolt (10). Install the pump belt onto the engine according to the belt diagram. Replace the fan and fan shroud. Check for proper clearances between the fan and the clutch pump. Replace the air cleaner assembly if removed and connect the battery cable.


**CAUTION:** Check all engine compartment hoses and wiring to insure they are not kinked, touching any high temperature item, or do not interfere with any linkage components.

**NOTE:** Due to OEM assembly tolerances, visually make certain that there is adequate clearance between fan and drive pulley.

## FMK46A-8

## 1999-04 FORD TRUCK F250-550 Super Duty - 1997-19 FORD VAN E150-450

**5.4LV8 Gas Triton & 6.8LV10 Gas Triton -** For use W-WO AC / Requires SAE Two Bolt "A" Flange Pump / Requires 8 Groove Clutch / Recommended no more than 5HP Load Per Ford Motor Company



BELT ROUTING

## PARTS LIST

- 1. FPC 368 (1)
- 2. 10mm x 60mm (3)
- 3. 10mm LW (7)
- 4. FMB 460A (1)
- 5. 10107 1.5 ST (2)
- 6. .080 shim (2)
- 7. 10mm x 60mm 10.9 (2)
- 8. 10mm nut (2)
- 9. 8920236 Tensioner (1)
- 10. 12mm x 80mm (1)
- 11. 12mm x 65mm (1)
- 12. 12mm FW

- 13. GPCD 8 (1)
- 14. FMB 391 Bushing (1)
- 15. 3/8 x 1 1/2 NC (2)
- 16. 3/8 FW (2)
- 17. 3/8 LW (2)
- 18. 3/8 NC Nut (2)
- 19. Clutch Pump Assembly (Sold Separately)
- 20. Coil (Sold Separately)
- 21. Clutch (Sold Separately)
- 22. (5080595) Dayco Belt (not shown)